


# Block 4 Egress



**Across**

- 2. ejection sequence starts when one or both handles are pulled
- 6. pulled to release emergency oxygen to pilot's face mask
- 8. Emergency

\_\_\_\_\_ handle

12. \_\_\_\_\_ Canopy Jettison Handle

14. Removes canopy when internal/external canopy jettison handle is pulled or ejection sequence is initiated

15. Contains emergency equipment needed for survival

16. secures pilot to the seat

**Down**

1. Locks or unlocks the power inertia reel

3. locks or unlocks ejection control handles

4. \_\_\_\_\_ Canopy Jettison Handle

5. Indicates the egress and/or canopy escape system is unsafe

7. allows or restricts the pilot's movement

9. release the parachute from the pilot over water

10. Attaches the pilot's upper body to the seat

11. Ejection seat is called

13. located on the left side of the seat